

Instructions for Installing Fold Away Footrest

Step 1 Open up your chair completely.

Step 2 Remove wrapping from footrest and extend all parts and place on floor in front of chair. Remove package of 2 bolts, washers and nuts attached to the fabric of the footrest.

Step 3 Place the steel plates of the footrest under the front black plastic feet of the chair.

Step 4 Put the bolts first up through the holes of the plates then the front feet of the chair. Place washer on top with nut and hand tighten.

Step 5 Fold up chair with footrest tucked under the seat and straddling the front cross bar, place chair on its back on a table. Tighten bolts and nuts with Phillips screwdriver and pliers.

Tools needed: Phillips Screwdriver, pliers

